



Hole Chart

Hole	Size		Used For
	H.M Door	Wood Door	
A	1-1/8 (29) Dia.	1-1/8 (29) Dia.	Lever/Knob
B	1-1/4 (32) Dia.	1-1/4 (32) Dia.	Cylinder (O/S)
C	1-1/4 (32) Dia.	1-1/4 (32) Dia.	Cylinder (I/S)
D	5/8 (16) Dia.	5/8 (16) Dia.	Thumbturn (I/S)
E	5/8 (16) Dia.	5/8 (16) Dia.	Cointurn (O/S)
F	3/8 (10) Dia.	3/8 (10) Dia.	Escutcheon Thrubolts

Notes:

1. All dimensions given in inches (mm)
2. Not to scale

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

8800 MORTISE LOCKS

WOOD AND H.M. DOOR PREPARATION
VN ESCUTCHEON INDICATOR TRIM

Contact us for support at 1-855-557-5078.

ASSA ABLOY

SUPERSEDES	01/21	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7088-1005	SHEET	1 of 2
		DATE	11-23

LOCK FUNCTION	HOLES IN DOOR
8802 8862 8865	A, D, E, F
8808	A, B, F
8808-2 8811-2 8812-2 8818-2 8860-2	A, B, C, F
8809 8820 8822 8827 8832 8840 8847 8860 8861 8864 8867	A, B, D, F
8866	A, D, F

ADD HOLES

INDICATOR CODE	ADD HOLES
V*0 (INDICATOR OUTSIDE)	E
V0* (INDICATOR INSIDE)	D
V** (INDICATOR BOTH SIDES)	D, E

<p>RESPONSIBILITY DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.</p>	<p>8800 MORTISE LOCKS WOOD AND H.M. DOOR PREPARATION VN ESCUTCHEON INDICATOR TRIM</p> <p>Contact us for support at 1-855-557-5078.</p>	<p>ASSA ABLOY</p>	
		<p>SUPERSEDES 01/21</p> <p>TEMPLATE NUMBER 7088-1005</p>	<p>DO NOT SCALE DRAWING</p> <p>SHEET 2 of 2</p> <p>DATE 11-23</p>