



**NOTES:**


1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Provide adequate structural support to maintain door integrity during operation.
6. Prepare mounting holes when installing trim.



534F



Section X - X



DISCONTINUED

**RESPONSIBILITY**  
 DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**534F Trim**  
 With 1500(F), 2100(F) or 7100(F) Series Rim, Mortise and Vertical Rod Exit Devices  
 Wood or Composite Door Preparation  
**Contact us for support at 1-855-557-5078.**

ASSA ABLOY

SUPERSEDES	8/99	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7400-1534	DATE	12-23

Experience a safer and more open world

Copyright © 1999, 2023, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.