


Notes:


1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. For door reinforcement see template T30800.
6. Prepare mounting holes when installing trim.
7. Provide adequate internal support to prevent door deformation after trim is bolted to the device.
8. Dimensions given about a centerline are symmetrical.
9. Unspecified radius 1/8 maximum.

NOTE: Wire access hole must be prepared if a wire raceway in the door is not provided. (Device will be used as raceway.)



9903 and 9905

Note: Lever design prefix does not affect door prep.



9903 and 9905 (Electric Trim)

ED5000 Series

SecureBolt, Rim and Surface Vertical Rod Exit Devices
Metal Door Preparation



www.corbinrusswin.com

SUPERSEDES	T30968	DO NOT SCALE DRAWING
TEMPLATE NUMBER	T30968-1	DATE 5-04