


Notes:


1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Provide adequate structural support to maintain door integrity during operation.
6. Prepare mounting holes when installing trim.
7. Dimensions given about a centerline are symmetrical.
8. Unspecified radius 1/8 maximum.

Note: Wire access hole must be prepared if a wire raceway in the door is not provided. (Device will be used as raceway.)



9903 and 9905

Note: Lever design prefix does not affect door prep.



9903 and 9905 (Electric Trim)
ED5000 Series
 SecureBolt, Rim and Surface Vertical Rod Exit Devices
Wood or Composite Door Preparation



SUPERSEDES	T30969	DO NOT SCALE DRAWING
TEMPLATE NUMBER	T30969-1	DATE 5-04