



**Notes:**

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Dimensions are in inches (mm).
3. LHR door shown. Preparation is typical for both door hands.
4. Provide adequate structural support to maintain door integrity during operation.
5. Prepare mounting holes when installing trim.
6. Dimensions given about a centerline are symmetrical.
7. Unspecified radius 1/8 maximum.
8. Provide 1/2 (13) Dia. raceway for motor wire harness from inside door face at Hole "A" to top of trim cutout on outside door face. Wire harness shall be free to run thru interior of door without obstructions. See Sheet 2 for raceway reference angles.
9. For Remote Power requirements, see Sheet 2.



9800 & 9M800 Series

Note: Lever design prefix does not affect door prep.



**RESPONSIBILITY**

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**9833, 9834, 9M833 and 9M834  
(Access 800® Series Trim)  
ED5000 Series**

**SecureBolt™, Rim and Mortise Exit Devices  
Wood or Composite Door Preparation**




**ASSA ABLOY**

www.corbinruswin.com

|                 |          |                      |
|-----------------|----------|----------------------|
| SUPERSEDES      | T30992-1 | DO NOT SCALE DRAWING |
| TEMPLATE NUMBER | T30992-2 | SHEET DATE           |
|                 | 1 of 2   | 03-18                |

## Remote Power Supply & Motor Wire Raceway Door Details



### RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**9833, 9834, 9M833 and 9M834**  
**(Access 800® Series Trim)**  
 ED5000 Series  
 SecureBolt™, Rim and Mortise Exit Devices  
**Wood or Composite Door Preparation**

**Corbin  
Russwin**  
**ASSA ABLOY**

www.corbinruswin.com

|                 |          |                      |
|-----------------|----------|----------------------|
| SUPERSEDES      | T30992-1 | DO NOT SCALE DRAWING |
| TEMPLATE NUMBER | T30992-2 | SHEET                |
|                 | 2 of 2   | DATE                 |
|                 |          | 03-18                |