


- Note
1. Do not scale.
  2. Tolerance on all dimensions  $\pm 1/64$ ".
  3. Recommend all tapped holes be drilled and tapped in field.
  4. Surface of door where exit device is to be applied must be flush.

Exit Device Function	Cutout Thru Door	Cutout Thru One Side Of Door Only		
		Dim "A"	Dim "B"	Dim "C"
50				
10, 55, 57	*1-3/8" Dia.	2-5/8"	1-5/16"	2-1/8"
10T, 55T	1-3/8" Dia.	3-1/8"	1-3/8"	1-1/2"

\* CYLINDER HOLES NOT REQUIRED FOR 57 OR 55 FUNCTION WHEN USED WITH LEVER TRIM, OR 3357T AUXILIARY CONTROL IS USED



**RESPONSIBILITY**

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**ED3400(A)**  
**Surface Vertical Rod Exit Device**  
**Wood Door & Metal Door**

**Corbin Russwin**  
**ASSA ABLOY**

www.corbinrusswin.com

SUPERSEDES T31221-1 DO NOT SCALE DRAWING  
TEMPLATE NUMBER T31221-2 DATE 08-15