


Notes:

- 1) Do not scale drawing.
- 2) Dimensions are in inches(mm).
- 3) LHR active pair shown. Preparation is typical for both hands.
- 4) Minimum door stile width: 4-1/2(114).
- 5) Prepare mounting holes when installing the device.
- 6) For square door edges, or other center clearance, compensate locating dimensions as required to maintain strike to device distance shown.
- 7) For recommended door reinforcements see template T30800.

Unreinforced doors require SNB option to mount the hardware.

- 8) Holes for optional SNB: 9/32(7.00) dia., inside door face; 3/8(9.50) dia., outside door face.
- 9) Provide door stiffeners, as needed to prevent door collapse due to installation with power tools, door use, or abuse.
- 10) Device mount to hinge stile (not shown) requires holes location and preparation during device installation.
- 11) For trim preparation see appropriate trim template.
- 12) For electrical devices (suffixes M91, M92, M93, M94, M97) also see template T30890.



ED5202 Series Double Cylinder Rim Exit Devices with Optional S02 Strike
 Application to Pair of Metal Doors without Mullion
 (Not for Fire Labeled Devices)

Corbin Russwin[®]
 www.corbinrusswin.com

SUPERSEDES	DO NOT SCALE DRAWING
TEMPLATE NUMBER	DATE
T30976	8-03