



Notes:

1. Minimum Stile Width 4-1/2(114).
2. For recommended door reinforcements see template T30800. Unreinforced doors require optional SNB to mount the device components.
3. Unless otherwise specified, door and frame preparation and dimensional tolerances must conform to ANSI A115.1. Lock support required as shown.
4. For outside trim preparation see appropriate trim template.
5. Prepare mounting holes when installing the device.
6. LHR door shown. Preparation is typical for both door hands.
7. Dimensions are in inches (mm). Do not scale drawing.
8. Holes for optional SNB: 9/32(7.00)Dia. inside door face; 3/8(9.50) Dia. outside door face.
9. Dimensions given about a centerline are symmetrical.
10. Device mount to hinge stile (not shown) requires holes location and preparation during device installation.
11. For electrical device suffixes "-Safe", "-Secure", M91, or M93: 1/2 (12.70) diameter, this face, plus prep shown on template T30890.
12. For electrical device suffixes M92, M94, or M97 also see template T30890.
13. Latchbolt centerline is 23/32 (18.2) below & Auxbolt centerline is 3/16 (4.8) above the centerline of lockfront.

ED5600 & ED5600A Series
Mortise Exit Devices with ANSI A115.1 Strike
 Application for Metal Door and Frame



www.corbinrusswin.com

SUPERSEDES T30809-1 DO NOT SCALE DRAWING
 TEMPLATE NUMBER T30809-2 DATE 1-04