



### Strike Preparation

#### Notes:

- Do not scale drawing.
- Dimensions are in inches (mm).
- LHR active pair shown. Preparation is typical for both hands.
- Minimum door stile width 4-1/2(114).
- Prepare mounting holes when installing device.
- Provide adequate structural support to maintain door integrity after device installation with power tools, door use, or abuse.
- Device mount to hinge stile (not shown) requires hole(s) location and preparation during device installation.
- For outside trim preparation see appropriate trim template.

- Unless otherwise specified, door preparation and dimensional tolerances must conform to ANSI A115.1 (lock) and A115.14 (strike).
- Dimensions given about a centerline are symmetrical.
- Wood screws (#14x1-1/4", by others) permitted in solid core wood doors if pilot holes are used for installation, when door label allows its use.
- For electrical device suffixes "-Safe", "-Secure", M91, or M93: 1/2 (12.70) diameter thru this face, plus prep shown on template T30890.
- For electrical device suffixes M92, M94, or M97 also see template T30890.
- Latchbolt centerline is 23/32 (18.2) below & Auxbolt centerline is 3/16 (4.8) above the centerline of lockfront.

**ED5600 & ED5600A Series Mortise Exit Devices  
with Optional SB134 or SB214 Open Back Strike**  
Application for Pair of Wood or Composite Doors without Mullion

**Corbin  
Russwin**<sup>®</sup>  
www.corbinrusswin.com

SUPERSEDES T30845-1 DO NOT SCALE DRAWING  
TEMPLATE NUMBER T30845-2 DATE 9-99