


SUPERSEDES	T30907-2	DO NOT SCALE DRAWING	
TEMPLATE NO.	T30907-3	SHEET 1 of 2	DATE 1-02

681F77 Top Strike Preparation (See Note 6)



Notes:

- Do not scale drawing.
- Dimensions are in inches (mm).
- Preparation is typical for both hands.
- Minimum door stile width: 4-1/2 (114).
- Prepare mounting holes when installing the device.
- Drawing shows elevation (frame bisected on strike center), bottom view looking up and side view.
- Provide adequate structural support to maintain door integrity after device installation with power tools, door use, or abuse.
- This template does not cover devices without bottom rod (M55 Option).
- Door located in frame for door silencers. If not used, compensate this dimension to seat the door against the stop without rattle.
- Device mount to hinge stile (not shown) requires hole location and preparation during device installation. Door structural requirements are similar for both stiles.
- For outside trim preparation see appropriate trim template.
- For electrical devices (suffixes M91, M92, M93, M94, M97) also see template T30890.
- Bottom bolt should retract to 5/32 (4.0) above floor strike. Floor coverings in the door path must be laid accordingly.

ED5860 & ED5860B Series
Concealed Vertical Rod Exit Devices
 Application for Wood Door & Metal Frame
 with Optional SO9 Floor Strike

Corbin
Russwin
 www.corbinrusswin.com

SUPERSEDES	T30907-2	DO NOT SCALE DRAWING
TEMPLATE NO.	T30907-3	SHEET 2 of 2 DATE 1-02