


TEMPLATE CROSS REFERENCE

DEVICE	DESCRIPTION	TEMPLATE
RIM	EDB200 & EDB200B SERIES	T30436
	EDB200 & EDB200B SERIES x M61 & M62	T30491
	EDB200A SERIES	T30465
	ED9200 & ED9200B SERIES	T30441
	ED9200 & ED9200B SERIES x M61 & M62	T30490
	ED9200A SERIES	T30462
	ED9200 SERIES x M60	T30487
VERTICAL ROD	ED9200 SERIES x M60 & M61	T30489
	EDB400 SERIES	T30437
	EDB400A SERIES	T30467
	ED9400 SERIES	T30431
	ED9400A SERIES	T30443

NOTES:

- BACKSET IS MEASURED FROM CENTERLINE OF BEVEL WHICH IS CENTERPOINT OF DOOR THICKNESS. REFER TO APPROPRIATE DEVICE TEMPLATE FOR BACKSET DIMENSION.
- DIMENSIONS GIVEN IN INCHES AND (MM).

LHR SHOWN  
RHR OPPOSITE



OUTSIDE FACE OF DOOR  
(TRIM SIDE)

RESPONSIBILITY

Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames, regardless of the type, material, or method of construction.

P 357

PULL AND CYLINDER EXIT TRIM

**Corbin Russwin**  
www.corbinrusswin.com

DO NOT SCALE DRAWING			
SUPERSEDES	T 30485	DR.	BTH
DATE	04/02/93	APP.	<i>[Signature]</i>
TEMPLATE NUMBER	T 30485 - 1		