

#### Notes:

- This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
- 2. Dimensions are in inches (mm).
- 3. LHR door shown. (RHR opposite)
- 4. Provide adequate structural support to maintain door integrity during operation.
- 5. Prepare mounting holes when installing trim.
- 6. Dimensions given about a centerline are symmetrical.
- 7. Unspecified radius 1/8 maximum.





Note: Lever design prefix does not affect door prep.



### RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

SE LP10, SN200/210 9M600 Series Trim for ED5600N Series Exit Devices Wood, Composite or Metal Door Preparation Corbin 778° Russwin 778°

**ASSA ABLOY** 

www.corbinrusswin.com


SUPERSEDES T31217 DO NOT SCALE DRAWING
TEMPLATE NUMBER SHEET DATE

T31217-1

1 of 2 12/20

# **LHR** Door

# **RHR** Door



#### RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

SE LP10, SN200/210 9M600 Series Trim for ED5600N Series Exit Devices **Wood, Composite or Metal Door Preparation** 

ASSA ABLOY

www.corbinrusswin.com

SUPERSEDES DO NOT SCALE DRAWING T31217

2 of 2

T31217-1

12/20