


- NOTES:
- BACKSET IS MEASURED FROM CENTERLINE OF BEVEL WHICH IS CENTERPOINT OF DOOR THICKNESS. REFER TO DEVICE TEMPLATE FOR BACKSET.
 - DIMENSIONS GIVEN IN INCHES AND (MM).
 - REFER TO CHART FOR SPECIAL HOLES REQUIRED BY TRIM FUNCTION.

TEMPLATE CROSS REFERENCE

DESCRIPTION	TEMPLATE
ED6200 SERIES RIM DEVICE	T30566
ED6200 SERIES x SD4	T30589

LHR SHOWN
RHR OPPOSITE

TRIM	A	B
T510 T650		●
T550 T650		
T555 T655	●	●
T557 T657	●	



INSIDE FACE OF DOOR (DEVICE SIDE)

SUPERSEDES: W25664, W25665
23173C, 23174C

RESPONSIBILITY

Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames, regardless of the type, material, or method of construction.

T 510 T 610
T 550 T 650
T 555 T 655
T 557 T 657

THUMBPIECE PULL SECTIONAL TRIM
CROSSBAR RIM DEVICE

Corbin Russwin
www.corbinrusswin.com

DO NOT SCALE DRAWING

SUPERSEDES	SEE ABOVE	DR.	BTH	APP.
DATE	03/31/93	TEMPLATE NUMBER	T 30584	