

TH910

Heavy Duty Thumbpiece Trim For use with ED5000 Series Exit Device

Metal, Wood or Composite Doors




Figure 1

*Shown for LHR door

For installation assistance contact Corbin Russwin
1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com

Copyright © 2018 Corbin Russwin, Inc., an ASSA ABLOY Group company.
All rights reserved. Reproduction in whole or in part without the express written permission of Corbin Russwin, Inc. is prohibited.

(617417700) FM257 05/18

ASSA ABLOY, the global leader
in door opening solutions

TH910 Heavy Duty Thumbpiece Trim

For ED5000 Series Exit Device

Installation Instructions



ASSA ABLOY


1

Template Top

Holes Marked "X" (5 Places)	
Metal Doors:	
Inside Face	5/16" (8) Dia.
Outside Face	1/2" (13) Dia.
Wood Doors: 1/2" (13) Dia. Thru	

Dimensions in inches (mm).

CAUTION: Office copiers and desktop printers may change the size of a drawing and make the template inaccurate to use as a door marker. If this is not the original template packed with the trim, use only the dimensions written on the template to locate the holes on the door. Do not use the template as a door marker.



TH910 Heavy Duty Thumbpiece Trim

For ED5000 Series Exit Device


Installation Instructions



ASSA ABLOY

2

Template Bottom



3

Installation

1. Check box contents. (Figure 1)
2. After marking door inside face for device location (Device Instructions), transfer “Vertical Reference Centerline” from inside to outside door face. (Figure 2)
3. Transfer “Horizontal Reference Centerline” from inside to outside door face.
4. Align trim template and tape to outside door face. (pages 2 and 3)
5. Spot holes and prepare door for trim.





Figure 2

6. Mount trim to door through holes “B”. Fasten, finger tight only, with three (3) screws and washers seating on door, as shown. (Figure 3) Bottom screw and washer engages lower post on pull.

NOTE:

- **Device is bolted to trim using holes “A” (closest to door lock edge).**
- **Trim spindle engages with vertical cross hole of cam slot.**
- **Screws and washers bolt trim to door using holes “B”.**




Figure 3

7. Cut trim spindle as shown. (Figure 4)

NOTE: Measure from device mounting surface (door face or shim surface).

8. Seat device so that trim spindle engages vertical cam slot, as shown. (Figure 3) Continue as shown in device instructions.




Figure 4

Corbin Russwin
225 Episcopal Road
Berlin, CT 06037
Phone: 800-543-3658
Fax: 800-447-6714
corbinrusswin.com

ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience