





	Wood Frame	Metal Frame
Dim 1	3/8" ϕ	3/4" ϕ

NOTES:


1. Refer to door template for proper (DPS) door position switch dimension (Dim 2) all dimensions are to be taken from the center lines (CL) of strike
2. Cylindrical lock strike shown. Strike will vary depending on product line
3. Refer to instruction sheet for proper installation of Door Position Switch



	Wood Frame	Metal Frame
Dim 1	3/8" ϕ	3/4" ϕ

NOTES:


1. Refer to door template for proper (DPS) door position switch dimension (Dim 2) all dimensions are to be taken from the center lines (CL) of strike
2. Cylindrical lock strike shown. Strike will vary depending on product line
3. Refer to instruction sheet for proper installation of Door Position Switch



	Wood Frame	Metal Frame
Dim 1	3/8" ϕ	3/4" ϕ

NOTES:

1. Refer to door template for proper (DPS) door position switch dimension (Dim 2) all dimensions are to be taken from the center lines (CL) of strike
2. Cylindrical lock strike shown. Strike will vary depending on product line
3. Refer to instruction sheet for proper installation of Door Position Switch



	Wood Frame	Metal Frame
Dim 1	3/8" ϕ	3/4" ϕ

NOTES:

1. Refer to door template for proper (DPS) door position switch dimension (Dim 2) all dimensions are to be taken from the center lines (CL) of strike
2. Cylindrical lock strike shown. Strike will vary depending on product line
3. Refer to instruction sheet for proper installation of Door Position Switch