


Opening	Dim.A	Dim B
To 100°	9-7/8 (251)	7-1/4 (184)
101° to 180°	7-1/8 (181)	4-1/4 (108)




**Notes:**

Door swing may be limited by door, frame, wall or hardware conditions.

Hollow-metal doors require channel or box-type reinforcement when thru-bolt mount is specified.

Sex-bolts required for wood or plastic faced fire-door mounting.

Minimum thickness recommended for reinforcements in hollow-metal doors and frames: .1046" (2.66mm) unless otherwise noted.



- Do not scale drawing.
- Left hand door shown.
- Dimensions are:  
inches  
millimeters

PREPARATION FOR FASTENERS		
TYPE OF FASTENER	DOOR OR FRAME	PREPARATION
#14 Type "A" Sheet Metal Screw	Wood	7/32" (5.5mm)
1/4-20 Machine Screw	Hollow Metal	#7(.201 dia.) or 5.10mm. drill — 1/4-20 tap
SNB (Sex Nut & Bolt) (Optional)	Hollow Metal	9/32" (7.00mm) thru ... 3/8" (9.50mm) door face Opposite to closer
	Aluminum or Wood	3/8" (9.50mm) thru ...
TBGN (Thru Bolt & Grommet Nut) (Optional)	All	9/32" (7.00mm) thru ... 3/8" (9.50mm) diameter 3/8" (10mm) deep, door Face opposite to closer

**1700BC-H Series Door Closers  
Door and Frame Preparation Template  
Parallel Arm Application With Hold Open Arm  
With or Without 1748 or 1758 Drop Plate**



ASSA ABLOY

www.nortondoorcontrols.com

TEMPLATE NUMBER	DATE
<b>7317-0102</b>	<b>01-09</b>