



Door Opening Angle		Dimensions			
Hold Open ★	Dead Stop	Butts and Offset Pivots		Center Pivots	
		A	B	A	B
85°	90°	7-1/2	12-7/8	8	13-3/8
90°	95°	6-3/4	12-1/8	7-3/8	12-3/4
95°	100°	6-1/4	11-5/8	6-3/4	12-1/8
100°	105°	5-3/4	11-1/8	6-1/4	11-5/8
105°	110°	5-1/4	10-5/8	5-7/8	11-1/4
110°	115°	4-7/8	10-1/4	5-1/2	10-7/8

★ Door must be free to swing 5° beyond hold-open position.

Notes:

Do not scale drawing.

Left hand door shown.

Dimensions are in inches.

Hollow-metal doors require channel or box-type reinforcement when thru-bolt mount is specified.

Sex-bolts required for wood or plastic faced fire-door mounting.

Minimum thickness recommended for reinforcements in hollow-metal doors and frames: .1046" (2.66mm).

Follow Conversion Chart for metric dimensions.

Preparation for Fasteners			
Fasteners	Application	Door or Frame	Drill Sizes
Sex nuts and bolts	Closer Drop Plate 2022 Bracket	Hollow Metal	9/32" (7.00mm) through 3/8" (9.50mm) door face opposite to closer
		Alluminum or Wood	3/8" (9.50mm) through
Through bolts and grommet nuts	Optional	All	9/32" (7.00mm) through 3/8" (9.50mm) dia. x 3/8" (10mm) deep, door face opposite to closer

inches	mm.	inches	mm.	inches	mm.
5/16	8	5-1/2	139.5	11-1/8	282.5
1/2	12.5	5-3/4	146	11-1/4	286
3/4	19	5-7/8	149	11-5/8	295.5
1-1/8	28.5	6-1/4	159	12	305
1-1/2	38	6-3/4	171.5	12-1/8	308
1-3/4	44.5	7-3/8	187.5	12-3/4	324
2-1/2	63.5	7-1/2	190.5	12-7/8	327
3	76	8	203	13-3/8	339.5
4	101.5	10-1/4	260.5		
4-7/8	124	10-5/8	270		
5-1/4	133	10-7/8	276		

**Unitrol® With 2022 Bracket
Series UNI-8300, UNI-8301,
UNI-8500, UNI-8501
Doors 33" - 41" (0.85-1.00m) Wide**

**Parallel Arm Installation Template
Flush Partitions
Stop Only or Hold Open Unitrol®
Backcheck or Delayed Action Door Closer
With or Without 8148 Drop Plate**



ASSA ABLOY

www.nortondoorcontrols.com

TEMPLATE NUMBER

7380-1355

DATE

09-08