


	Door Leaf Width	OAL (Overall Length)	Dim A	Dim B	Dim D
D6011-36	36 (914)	74-1/4 (1886)	5-9/16 (141)	30-9/16 (776)	30-9/16 (776)
D6011-38	38 (965)	78-1/4 (1988)	7-9/16 (192)	32-9/16 (827)	32-9/16 (827)
D6011-40	40 (1016)	82-1/4 (2089)	9-9/16 (243)	34-9/16 (878)	34-9/16 (878)
D6011-42	42 (1067)	86-1/4 (2191)	11-9/16 (294)	36-9/16 (929)	36-9/16 (929)
D6011-44	44 (1118)	90-1/4 (2292)	13-9/16 (344)	38-9/16 (979)	38-9/16 (979)
D6011-46	46 (1168)	94-1/4 (2394)	15-9/16 (395)	40-9/16 (1030)	40-9/16 (1017)
D6011-48	48 (1219)	98-1/4 (2496)	17-9/16 (446)	42-9/16 (1081)	42-9/16 (1081)

- Notes:
- Dimensions shown in inches / (mm) unless specified otherwise.
  - Electrical requirements:
    - Power input of 120VAC, 5Amp minimum
    - Accessories circuit for activation to operator and low voltage
  - For initial set up, doors must be un-latched and free to move
  - For additional installation instructions, see instruction sheet 80-9360-1029-020. Visit [www.nortondoорcontrols.com](http://www.nortondoорcontrols.com)
  - Refer to page 2 for proper handling of product

D6011 Series Template  
 shown on pairs of 36", 38", 40", 42", 44", 46", and 48" frames  
 shown with up to 5" Butt Hinges  
 Maximum reveal of 1/8"


Single Pull Side




NOTE:  
- All illustrations on this page shown  
with 36" (914mm) wide doors

Left Hand  
Door  
(view from below)

Right Hand  
Door  
(view from below)




Double Door Pull Side




Right Hand  
Door  
(view from below)

Left Hand  
Door  
(view from below)




Double Door Double Egress Left Hand




Interior

Left Hand  
Door




Single Push Side




Exterior  
Right Hand  
Door  
(view from below)

Exterior  
Left Hand  
Door  
(view from below)




Double Door Push Side




Exterior  
Left Hand  
Door  
(view from below)

Exterior  
Right Hand  
Door  
(view from below)




Double Door Double Egress Right Hand




Right Hand  
Door  
(view from below)



Interior



D6011 Series Template  
shown on pairs of 36", 38", 40", 42", 44", 46", and 48" frames  
shown with up to 5" Butt Hinges  
Maximum reveal of 1/8"



	Dim A	Dim B	Dim C	Dim D	Dim E	Dim F
D6011-36	5-9/16 (141)	30-9/16 (776)	4-1/16 (103)	30-9/16 (776)	5-3/4 (146)	9-1/2 (241)
D6011-38	7-9/16 (192)	32-9/16 (827)	4-1/16 (103)	32-9/16 (827)	7-3/4 (197)	11-1/2 (292)
D6011-40	9-9/16 (243)	34-9/16 (878)	9-9/16 (243)	34-9/16 (878)	4 (102)	8 (203)
D6011-42	11-9/16 (294)	36-9/16 (929)	10-1/16 (256)	36-9/16 (929)	5-3/4 (146)	9-1/2 (241)
D6011-44	13-9/16 (344)	38-9/16 (979)	12-1/16 (306)	38-9/16 (979)	5-3/4 (146)	9-1/2 (241)
D6011-46	15-9/16 (395)	40-9/16 (1030)	14-1/16 (356)	40-9/16 (1017)	5-3/4 (146)	9-1/2 (241)
D6011-48	17-9/16 (446)	42-9/16 (1081)	16-1/16 (408)	42-9/16 (1081)	5-3/4 (146)	9-1/2 (241)



- Notes:
- Do not scale drawing.
  - Operator shown for pull side double door application.
  - All dimensions are given in inches and millimeters.
  - Recommended thickness for reinforcements in hollow-metal doors and frames should provide a combined material thickness of .164 (4.2) MIN.
  - This template information based upon use of 5 (127) maximum width butt hinges or 3/4 (19) offset pivots.

D6011 Series Template  
shown on pairs of 36", 38", 40", 42", 44", 46", and 48" frames  
shown with up to 5" Butt Hinges  
Maximum reveal of 1/8"

**Norton**  
ASSA ABLOY  
www.nortondoorcontrols.com

TEMPLATE NUMBER	REV	DATE
80-7360-1051-020	2	10/20