


Preparation for Fasteners								
Fasteners	Application	Door or Frame	Drill Sizes					
Sex-nuts and bolts	Closer Drop plate	Hollow Metal	9/32" (7.00mm.) through 3/8" (9.50mm.) door face opposite to closer					
		Aluminum or wood	3/8" (9.50mm.) through					
#14 x 1-1/4" (32mm.) type "A" S.M. screws	Soffit plate 6190 Bracket	Wood	3/16" (4.30mm.)					
1/4-20 machine screw		metal	drill: #7 (.201"dia.) tap: 1/4-20					
Through bolts and grommet nuts		All	9/32" (7.00mm.) through 3/8" (9.50mm.) dia. x 3/8" (10mm.) deep, door face opposite to closer					



Notes:

- Do not scale drawing.
 All dimensions shown in inches (mm.).
- · Left hand door shown.
- Caution: Hollow metal doors require channel or box type reinforcement.

Door Opening Angle		Dimensions*									
Hold Dead Stop	Dead	Butts and Offset Pivots			Center Pivots						
	Dimension A		Dimension B		Dimension A		Dimension B				
		Inches	mm.	Inches	mm.	Inches	mm.	Inches	mm.		
85°	90°	101/4	260	101/2	267	111/4	286	111/2	292		
90°	95°	95/8	244	97/8	251	101/2	267	10¾	273		
95°	100°	91/8	232	93/8	238	10	254	101/4	260		
100°	105°	8¾	222	9	229	91/2	241	93/4	248		
105°	110°	83/8	213	85/8	219	91/8	232	93/8	238		
1 10°	115°	8	203	81/4	210	83/4	222	9	229		

- * "A" and "B" dimensions measured from centerline of hinge or pivot.
- ** Door must be free to swing up to 5° beyond hold open position.

Unitrol® Standard Application Series UNI-7500 & UNI-7700
Parallel Arm Installation Stop Only or Hold Open Unitrol®
Backcheck or Delayed Action Door Closer
With or Without 7788 Drop Plate
Doors 28" - 32" (0.70-0.80m) Wide

ASSA ABLOY

TEMPLATE NUMBER REV

RIXSON

7377-1351

3 12/21

Approved 2022-02-25