

NOTES:

1. Do not scale drawing.
2. Dimensions are given in inches (mm).
3. Pivot is usable with doors set flush with frame as well as 1/8 (3.2) setback.
4. Right hand shown.
5. Pivot does not carry weight of door.
6. Bevel edge of door: 1/8 in 2 (3.2 in 50.8)

F219 Side Jamb Pivot
Half Surface - Steel
3/4" Offset - Handed

Approved 2024-06-06



TEMPLATE NUMBER	REV	DATE
IS-F219	3	05/24

Handed


F219 Side Jamb Pivot Installation Instructions

3/4" Offset

Door should already be hung with top pivot and bottom pivot (or floor closer)


1.  Mortise door & frame per template on reverse side.


2.  Affix pivot to door & frame.


3.  Align pivot point from top pivot to bottom arm. (See diagram)


4.  Loosen arm screw*.


5.  Remove hex cap.

6.  Turn stud screw clockwise. Raise the door to the desired height.

7.  Using shims furnished with bottom arm, fill gap between arm and base.



8.  Turn stud screw counterclockwise until door rests on shims.

9.  Tighten arm screw on spindle. Open and close door several times. Re-tighten arm screw.

10.  Replace hex cap.

* If bottom arm is for a Uni-Chek 67/68 or 117 pivot, make sure the arm is sitting all the way down on the base. Make NO adjustments to the M19.



F219 Side Jamb Pivot
Half Surface - Steel
3/4" Offset - Handed

NORTON RIXSON
ASSA ABLOY

TEMPLATE NUMBER
IS-F219

REV DATE
3 05/24

Approved 2024-06-06