


VD2 - 6EWS RETROFIT KIT TEMPLATE

FOR REPLACING 996 ESCUTCHEON ON VD98/99 RIM EXIT

TEMPLATE: 629336
REV.0 12-09-19

PULL SIDE FACE OF DOOR



Adaptor Instructions:

1. Drill wire access hole as shown on template
2. Enlarge drive spindle / center hole on push side of door as shown on back of template
3. Drill mounting holes for battery box on push side of door as shown on back of template
4. Adjust drive spindle length to use center pin hole
5. Insert scar plate onto back of trim if required to cover bottom of original door prep
6. Install trim per included instruction using (4) 1/4-20 screws included with kit

Notes:

1. Verify template is printed to scale
2. Height of Escutcheon = 11-25/32" [299.2]
Width of Escutcheon = 2-31/32" [75]
Trim Projection = 3-1/8" [79.4]



PDQ Manufacturing
2230 Embassy Dr.
Lancaster, PA 17603
833-273-7832
833-2 PDQTECH
www.pdqlocks.com

VD2 - 6EWS RETROFIT KIT TEMPLATE

FOR REPLACING 996 ESCUTCHEON ON VD98/99 RIM EXIT

TEMPLATE: 629336
REV.0 12-09-19

BATTERY BOX PREP FOR 6EWS RIM DEVICE TRIM




TABLE "A"
METAL DOORS: USE 7/64" [2.8] PILOT DRILL
WOOD DOORS: USE 1/8" [3.2] PILOT DRILL



PDQ Manufacturing
2230 Embassy Dr.
Lancaster, PA 17603
833-273-7832
833-2 PDQTECH
www.pdqlocks.com