
# **Aluminum Continuous Geared Hinges**



## **Full Concealed**



- Full concealed, heavy duty
- 1/16" door inset
- Safety hinge application when used without a frame stop
- Used primarily in schools, nursing homes and day care facilities to avoid fingers and/or other objects being closed in the door
- %16" gap between frame leaf and door leaf when door is closed
- 48" door width maximum
- 450 lbs. door weight maximum
- **Fasteners**: 12-24 x %" undercut self-drilling, thread-forming tek machine screws
- **Standard lengths**: 79", 83", 85", 95" and 120"
- Finishes: Clear, dark bronze and black anodized

# -25/32" 3/32" INSET 21/32" 1-9/16" 1/16" **A140 HD** A140 LL **Standard Features**

- Full concealed, heavy duty
- 3/32" door inset
- Door edge protector lip
- For use on 1-3/4" thick door
- 48" door width maximum
- 450 lbs. door weight maximum
- "LL" model for doors up to 1,000 lbs. (lead-lined staggered hole pattern)
- **Fasteners**: 12-24 x %" undercut self-drilling, thread-forming tek machine screws
- **Standard lengths**: 79", 83", 85", 95" and 120"
- Finishes: Clear, dark bronze and black anodized
- **Fire Rating** 
  - Approved for use on metal swinging type fire doors rated up to and including 90 minutes (Specify "FR" option for 3 hour rating)
  - Approved for use on wood swinging type fire doors rated up to and including 60 minutes (Specify "FR" option for 90 minute rating)

## **Options Available**

See pages F-7 to F-8 for option availability and details

#### **Options Available**

See pages F-7 to F-8 for option availability and details



### INSTALLATION INSTRUCTIONS FOR FULL CONCEALED HINGES

A110HD/LL, A111HD/LL, A130HD, A135HD, A140HD/LL, A150HD/LL, A160HD/LL A240HD/LL, A260HD/LL, A270HD/LL, A280HD/LL & A410HD/LL

- A. All uncut standard length hinges are non-handed and can be used for right or left hand doors.
- B. Standard length hinges are supplied slightly shorter than nominal door height to accommodate threshold and carpeting clearances.

#### **CUTTING THE HINGE TO FIT**

- Keep hinge in the closed position
- Determine HANDING if required. Not all hinges will become handed after cutting.
- Cut one end of the hinge only. Cut end will be installed at the bottom (Six-hole pattern remains at the top)
- Use a Metal Cutting Saw cut through the gear cap first.

Note: If cut length interferes with a set screw bearing remove it and switch it with a plain bearing above the cut location.

#### **FRAME PREP**

With the hinge in the open position

1. Locate the top of the hinge 1/8" below the header

With the frame leaf flange tight against the frame

2. Mark or Center Punch hole locations

Note: If using wood screws drill a 5/32" pilot hole

DO NOT ATTACH HINGE TO FRAME AT THIS TIME

#### ATTACH THE HINGE TO THE DOOR

- 4. Position Door Leaf on door. Door leaf alignment flange or door leaf lip must be seated against door edge.
- 5. Align the top end of the hinge to be absolutely flush with the top of the door.
- 6. Mark or Center Punch hole locations
- 7. Using the provided Self Drilling/Thread Forming Screws and the proper drive bit please proceed to attach the hinge to the door **Note:** If using wood screws drill a 5/32" pilot hole.

#### ATTACHING DOOR TO FRAME

- 8. Position door 90 degrees to frame
- 9. Shim door to the proper height to line up the screw holes in hinge frame leaf with the marks at the top of the frame.
- 10. Install two screws at the top of the hinge to hold in place
- 11. Remove shim and align the remaining holes. Install two additional screws in the middle and at the bottom.
- 12. Check door for proper swing and clearance before installing remaining screws, making necessary adjustments.
- 13. Install the remaining fasteners after any adjustments are made.

#### **REINFORCING AND RIVNUTS**

- No reinforcing is necessary except on extremely high-frequency, extremely heavy or extra-wide doors.
- Rivnuts are recommended for use in the frame when the door exceeds 450lbs.

Note:RIVNUTS are not to be used with Fire Rated Hinges

#### PAIRS OF DOORS WITH MULLIONS

- If the mullion is between the doors, install as single doors.
- If the mullion is behind the doors, install as a double doors.

#### **GROUT/SLUSHED-IN FRAMES**

It is recommended that a mudguard be installed behind the frame for ease of installation. Do not use self-drill screws with grouted steel frames without a mudguard. If no mudguard has been used, drill holes through frame and remove grout for screw clearances. Do not oversize hole.

SCREW DETAIL	
	12-24 x 3/4" PHILLIPS FLAT HEAD, UNDERCUT, SELF DRILLING, THREAD FORMING TEK MACHINE SCREW
DOOR	12-24 x 3/4" PHILLIPS FLAT HEAD, UNDERCUT, SELF DRILLING, THREAD FORMING TEK MACHINE SCREW


Note: #12 x 1-1/2" FLAT HEAD UNDERCUT WOOD SCREWS AVAILABLE UPON REQUEST

The following actions will void any warranty, expressed or implied.

- Failure to Install the hinge according to ABH's specifications and requirements
- Use of Fasteners other than those supplied with the hinge.
- Unauthorized field modifications including removing any of the bearings, altering the original finish or painting the hinge.



www.abhmfg.com E-mail: abhinfo@abhmfg.com Architectural Builders Hardware Mfg., Inc. 1222 Ardmore Ave., Itasca, IL 60143 630,875,9900; FAX 800,9FAXABH (932,9224) FM INSTALLATION-05.DWG FULL CONCEALED INSTALLATION INSTRUCTIONS PAGE 1 OF 1 REVISED 9-17-20





® www.abhmfg.com

E-mail: abhinfo@abhmfg.com Architectural Builders Hardware Mfg., Inc. 1222 Ardmore Ave., Itasca, IL 60143 630.875.9900; FAX 800.9FAXABH (932.9224) A130-ALUMINUM GEARED HINGE-01.DWG

A130 ALUMINUM GEARED HINGE

© 2015 ABH Mfg., Inc. printed in USA

PAGE 1 OF 1 REVISED 9-10-20